



Your Direct Manufacturing Source

INSTALLATION INSTRUCTIONS

Roll-Out Mats

STEP 1 – Unpack Quickly

For best results, unpack and install Roll-Out Mats as soon as possible after delivery. The sooner the product is removed from packaging, the sooner it will lay flat after installation.

STEP 2 – Prepare Floor

Sweep and clean floor before unrolling Roll-Out Mats.



STEP 3 – Unroll Roll-Out Mats

Unroll Roll-Out Mats. Edges may be butted together or overlapped (see *Overlap Note* below) for seamless appearance and floor protection. Initially, the Roll-Out Mats will have curl marks - due to being rolled on a core or folded in a box for shipment - this is normal.

- Unroll option 1: For lay-flat results, unroll Roll-Out Mats in the sunlight on a clean surface. The warmer the conditions, the quicker the curls will straighten out and lay flat. Use a wide push broom to push air out - begin from the center and work your way out (side-to-side and length-to-length). Repeat as necessary. Place on sub-floor when desired and repeat broom-out.
- Unroll option 2: If you wish to unroll mats directly onto the floor, sweep floor clean of debris and unroll Roll-Out Mats. For best results, start unrolling process at the display area entrance; finishing at the back of the display. (Note: In cool to cold conditions, it may take 72+ hours for most curl marks to lay flat depending on the temperature. Be sure to push out air with a broom. It is OK to set up the rest of your display on it during this time.)

STEP 4 – Allow Roll-Out Mats to Relax

Allow flooring to relax and lay flat. For custom fit, allow product to relax in place before trimming around edges and corners. (Note: If the flooring is used under extreme temperature conditions, such as direct sunlight or air conditioned exhibit halls, the product may expand or contract as much as 2% after laying flat. For a custom fit, always allow product to relax before trimming around edges and corners.)



STEP 5 – Trim To Fit Poles And Corners

Trim edges with sharp scissors or utility knife.



STEP 6 – Finishing

Taping around edges is optional. Roll-Out Mats can expand or contract up to 2% with temperature changes. It is best if the mat is allowed to 'float' freely on the floor. If you choose to tape the seam between two floor mats, we recommend using indoor-outdoor carpet tape.

Note: Due to the manufacturing process, patterns of two pieces of flooring may not match or align exactly along the seam when two mats are laid side by side.



***Overlap note:**

Roll-Out Mats flooring that is 10' wide, has an "overlap flap" (approximately 1.5" to 2" wide) of unpatterned material running down one side.



Your Direct Manufacturing Source

50 East 42nd Street - 14th Floor New York, NY 10017
212-953-1116 -- 212-953-1117 Fax -- 800-569-2751 Toll Free